




SENSORS

SENSOR	Y/N	TYPE	MODULE	INPUT
B1	YES	KTY	CPU	T1
B2	YES	KTY	CPU	T2
S1	YES	KTY	EXP1	T2
S4	YES	KTY	EXP1	T3
S5	YES	KTY	EXP1	T4
S6	YES	Termostat	EXP1	T1
S13	YES	KTY	EXP1	T5
S22	YES	KTY	EXP1	T6
S23	YES	KTY	EXP1	T7

OUTPUTS

OUTPUT	Y/N	OPEN/CLOSE	MODULE	OUTPUT	RTM [s]
M4	YES		EXP1	R8A,R8B	
M5	YES		EXP1	R1	
M6	YES	OPEN	EXP1	R2	150
		CLOSE	EXP1	R3	
M9	YES		EXP1	R4	