




SENSORS

SENSOR	Y/N	TYPE	MODULE	INPUT
B1	YES	KTY	CPU	T1
B2	YES	KTY	CPU	T2
S1	YES	KTY	EXP1	T2
S2	YES	KTY	EXP1	T3
S3	YES	KTY	EXP1	T4
S4	YES	KTY	EXP1	T5
S5	YES	KTY	EXP1	T6
S6	YES	Termostat	EXP1	T1
S13	YES	KTY	EXP1	T7
S22	YES	KTY	EXP1	T8
S23	YES	KTY	EXP2	T1
S24	YES	Pt1000	EXP2	T2

OUTPUTS

OUTPUT	Y/N	OPEN/CLOSE	MODULE	OUTPUT	RTM [s]
M4	YES		EXP1	R8A,R8B	
M5	YES		EXP1	R1	
M6	YES	OPEN	EXP1	R2	150
		CLOSE	EXP1	R3	
M9	YES		EXP1	R4	
M17	YES		EXP1	R5	